




1



2



IF THE FLOOR LAMP IS NOT STABLE AFTER ASSEMBLE, PLEASE LOOSE THE SCREW OF LEGS A LITTLE TO ADJUST THE STABLE.